Shoring Location No. 1

FOR TEMPORARY SHORING AND POSITIVE PROTECTION FOR TEMPORARY SHORING, SEE PLANS AND TEMPORARY SHORING PROVISION.

BEFORE BEGINNING TEMPORARY SHORING DESIGN OR CONSTRUCTION, SURVEY EXISTING GROUND ELEVATIONS IN THE VICINITY OF SHORING LOCATIONS TO DETERMINE ACTUAL SHORING HEIGHTS.

DESIGN TEMPORARY SHORING FROM STATION $100+40\pm$ -L-, 2 FT RIGHT, TO STATION $101+60\pm$ -L-, 2 FT RIGHT, FOR THE FOLLOWING ASSUMED SOIL PARAMETERS AND GROUND WATER ELEVATION:

UNIT WEIGHT ($^{\gamma}$) = 120 LB/CF FRICTION ANGLE ($^{\varphi}$) = 30 DEGREES COHESION (c) = 0 LB/SF GROUND WATER ELEVATION = 36 FT ±

DO NOT USE CANTILEVER, BRACED AND/OR ANCHORED SHORING FOR TEMPORARY SHORING FROM STATION 100+40 \pm -L-, 2 FT RIGHT, TO STATION 101+60 \pm -L-, 2 FT RIGHT.

AT THE CONTRACTOR'S OPTION, USE A STANDARD TEMPORARY WALL FOR TEMPORARY SHORING FROM STATION $100+40\pm$ -L-, 2 FT RIGHT, TO STATION $101+60\pm$ -L-, 2 FT RIGHT. SEE STANDARD DRAWING NO. 1801.02 FOR STANDARD TEMPORARY WALLS.

WHEN BACKFILL FOR BRIDGE APPROACH FILLS OVERLAPS WITH THE REINFORCED ZONE OF TEMPORARY WALLS, USE SHORING BACKFILL OR BACKFILL MATERIAL REQUIRED FOR BRIDGE APPROACH FILLS, WHICHEVER IS BETTER, IN THE REINFORCED ZONE OF TEMPORARY WALLS.

Shoring Location No. 2

FOR TEMPORARY SHORING AND POSITIVE PROTECTION FOR TEMPORARY SHORING, SEE PLANS AND TEMPORARY SHORING PROVISION.

BEFORE BEGINNING TEMPORARY SHORING DESIGN OR CONSTRUCTION, SURVEY EXISTING GROUND ELEVATIONS IN THE VICINITY OF SHORING LOCATIONS TO DETERMINE ACTUAL SHORING HEIGHTS.


DESIGN TEMPORARY SHORING FROM STATION 102+40 \pm -L-, 2 FT RIGHT, TO STATION 103+60 \pm -L-, 2 FT RIGHT, FOR THE FOLLOWING ASSUMED SOIL PARAMETERS AND GROUND WATER ELEVATION:


UNIT WEIGHT ($^{\gamma}$) = 120 LB/CF FRICTION ANGLE ($^{\varphi}$) = 30 DEGREES COHESION (c) = 0 LB/SF GROUND WATER ELEVATION = 36 FT ±

DO NOT USE CANTILEVER, BRACED AND/OR ANCHORED SHORING FOR TEMPORARY SHORING FROM STATION $102+40\pm$ -L-, 2 FT RIGHT, TO STATION $103+60\pm$ -L-, 2 FT RIGHT.

AT THE CONTRACTOR'S OPTION, USE A STANDARD TEMPORARY WALL FOR TEMPORARY SHORING FROM STATION $102+40\pm$ -L-, 2 FT RIGHT, TO STATION $103+60\pm$ -L-, 2 FT RIGHT. SEE STANDARD DRAWING NO. 1801.02 FOR STANDARD TEMPORARY WALLS.

WHEN BACKFILL FOR BRIDGE APPROACH FILLS OVERLAPS WITH THE REINFORCED ZONE OF TEMPORARY WALLS, USE SHORING BACKFILL OR BACKFILL MATERIAL REQUIRED FOR BRIDGE APPROACH FILLS, WHICHEVER IS BETTER, IN THE REINFORCED ZONE OF TEMPORARY WALLS.





TRANSPORTATION
OPERATIONS PLAN
TEMPORARY SHORING DATA